Air Quality Sensor Performance Evaluation Center Evaluation Summary

Sensor Description

Manufacturer/Model: Elitech Temtop P20

Pollutants: PM_{2.5} mass concentration

> Time Resolution: 5 min.

Type: Optical



Additional Information

Field evaluation report:

http://www.aqmd.gov/aqspec/evaluations/field

Lab evaluation report:

http://www.aqmd.gov/aqspec/evaluations/laboratory

AQ-SPEC website: http://www.aqmd.gov/aq-spec

0

n

200

Unit 1


400

600

- Overall, the Temtop P20 sensors showed moderate to high accuracy (68% to 87%) over the PM_{2.5} mass concentration range tested. The Temtop P20 sensors underestimated PM_{2.5} measurements from FEM T640x in the laboratory experiments at 20 °C and 40% RH.
- The Temtop P20 sensors showed high precision for all test combinations (PM concentrations, T and RH) for PM_{2.5} mass concentrations
- The Temtop P20 sensors showed low intra-model variability in the field evaluation (IDs: 1, 2, and 3) and moderate intra-model variability in the laboratory evaluation (IDs: 2 and 3).
- Data recovery for all units was ~ 90-100% in the field evaluation and 100% in the laboratory evaluation.
- For PM_{2.5}, Temtop P20 sensors showed weak to strong correlations with the FEM T640 from the field (0.41 < R^2 < 0.88). The Temtop P20 sensors showed very strong correlations with the FEM T640x in the laboratory evaluations (R^2 > 0.99 for PM_{2.5}).
- The same three Temtop P20 units were tested both in the field (1st stage of testing) and in the laboratory (2nd stage of testing), but only Unit IDs 2 and 3 operated properly and were able to log data during the laboratory evaluation.

Field Evaluation Highlights

- Deployment period 08/26/2020 to 10/21/2020: the three Temtop P20 sensors showed weak to strong correlations with the corresponding T640 PM_{2.5} mass concentrations.
- The units exhibited low intra-model variability and data recovery for $PM_{2.5}$ was ${\sim}90{\text{-}}100\%$ from all units.



An R² approaching the value of 1 reflects a near perfect agreement, whereas a value of 0 indicates a complete lack of correlation.

Laboratory Evaluation Highlights

Accuracy (PM_{2.5})

A (%) =
$$100 - \frac{|\overline{X} - \overline{R}|}{\overline{R}} * 100$$


Steady State #	Sensor Mean (μg/m³)	FEM T640x (μg/m³)	Accuracy (%)
1	6.1	9.0	67.7
2	39.8	47.8	83.2
3	85.6	98.2	87.2
4	168.4	196.0	85.9
5	257.0	295.9	86.8

Accuracy was evaluated by a concentration ramping experiment at 20 °C and 40%. The sensor's readings at each ramping steady state are compared to the reference instrument.

A negative % means sensors' overestimation by more than two fold. The higher the positive value (close to 100%), the higher the sensor's accuracy.



Precision (PM_{2.5})




100% represents high precision.

Sensor's ability to generate precise measurements of PM_{2.5} concentration at low, medium, and high pollutant levels were evaluated under 9 combinations of T and RH, including extreme weather conditions like cold and dry (5 °C and 15%) cold and humid (5 °C and 65%), hot and humid (35 °C and 65%), or hot and dry (35 °C and 15%).

Coefficient of Determination

i.



The Temtop P20 sensors showed very strong correlations with the corresponding FEM PM_{2.5} data ($R^2 > 0.99$) at 20 °C and 40% RH.

Climate Susceptibility

From the laboratory studies, the Temtop P20 sensors' precision decreased with increasing temperature, while relative humidity had minimal effect; the sensors showed spiked conc. changes at the 65% RH change points for all temperature and PM conc. levels.

Observed Interferents

All documents, reports, data, and other information provided in this document are for informational use only. Mention of trade names or commercial products does not constitute endorsement or recommendation. As a Government Agency, the South Coast AQMD and its AQ-SPEC program highly recommend interested entities to make use and purchase decisions based on the requirements of their study design, the technical aspects and features of their specific project applications.